

Magic Fix



NON MARKING **MAGIC STICKY**



MagicFix



PRODUCT SETUP



Please clean the surface



Remove the protective cover from the Magic Sticky



Insert the buckle over the Magic Sticky



NON MARKING
MAGIC STICKY
CARRY 10 KGS



Push to middle part and fix Magic Sticky to the surface

Seat the item into the buckle and turn the cover

TO REUSE AGAIN



Please wash Magic Sticky



Dry and use again

SUITABLE SURFACES



SMOOTH GLASS




FIBER




WALLPAPER



WOODEN




PAINTED WALL



TILE-MARBLE



SCAN FOR
PRODUCT SETUP



MGK-700

MAGIC FIX SINGLE HANGER

70x70x185 mm • 24 Pcs



MGK-701

MAGIC FIX DOUBLE HOOK HANGER

70x70x150 mm • 24 Pcs



MGK-702

MAGIC FIX FIVE HOOKS HANGER

65x315x175 mm • 24 Pcs



MGK-703

MAGIC FIX TOILET PAPER HOLDER

100x50x130 mm • 24 Pcs



MGK-704

MAGIC FIX SOAP DISH

130x100x90 mm • 24 Pcs



MGK-705

MAGIC FIX TOWEL PAPER HOLDER

245x110x130 mm • 24 Pcs



MGK-706

MAGIC FIX LONG TOWEL HOLDER

400x110x110 mm • 24 Pcs



MGK-707

MAGIC FIX ROUND TOWEL HOLDER

250x150x45 mm • 24 Pcs



MGK-708

MAGIC FIX TOILET PAPER HOLDER LUX

140x80x120 mm • 24 Pcs



MGK-709

MAGIC FIX TOWEL DISPENSER LUX
260x85x130 mm • 24 Pcs




MGK-712

MAGIC FIX TOILET PAPER HOLDER WITH LID
80x120x170 mm • 24 Pcs



MGK-710

MAGIC FIX HAIR DRYER HOLDER
130x100x230 mm • 12 Pcs



MGK-713

MAGIC FIX PLASTIC SOAP HOLDER
126x140x125 mm • 24 Pcs



MGK-711

MAGIC FIX TOOTHBRUSH HOLDER
70x120x175 mm • 24 Pcs



MGK-714

MAGIC FIX TOILET PAPER HOLDER RESERVE
140x80x280 mm • 12 Pcs

